

TEIXEIRA TECH

Thank you for purchasing the **Teixeira Tech Brake Line Mounting Kit**. This kit is designed to be used with aftermarket steel braided brake lines. Below are pictures and instructions to help you understand how to route your brake lines and zip ties.

Parts and quantities:

- 4) zip tie adapters
- 4) zip ties



1) Route the zip tie through the adapter and under the brake line. Next, loop the zip tie around the brake line and back through the adapter. Repeat this process for all of the adapters and zip ties.

2) Wrap all of the zip ties around the upper a-arms and loosely attach the zip tie ends.



3) Position the brake lines away from the extreme ends of the a-arm. This will allow movement of the brake lines at the frame while in motion. It will also allow the spindle to rotate when steering the ATV without excessive pull on the brake line.

4) Tighten the zip ties and cut off the excess past the locking mechanism.