



Thank you for purchasing the **Teixeira Tech OEM Upper Ball Joint Replace Kit** for your **Honda TRX 450R/ER**. This kit has been developed to re-engineer your stock upper a-arms to allow upper ball joint replacement and camber adjustment.



1) Remove a-arm from quad. Remove plug from backside of a-arm. Measure 1 1/8" from inside of a-arm and draw line on top and bottom to be cut. Carefully, cut stock ball joint off as straight as possible.



2) Insert the sizing sleeve and the ball joint into the a-arm as shown in the photo above. The sleeve may be welded onto the a-arm if desired, but not necessary. If welding the sleeve, tack weld in place now and remove ball joint for final welding. Replace the a-arm onto the ATV and realign.

